

BARN DOOR GRIP ONLY

1. Determine where you want the grip to be on the door **horizontally**. If there is a vertical stile (board that goes from the top of the door to the bottom, on the door edge), normal placement is in the middle of this board. For example: If the stile is 4.5" wide, the center of the grip would be located in the middle, or 2.25" from the edge. If the door has no visible stiles, locate the grip 2.5" from the door edge. Mark this distance lightly with a pencil.
2. Determine where you want the grip to be on the door **vertically**. Normal placement is 33" from the bottom of the door to the bottom mounting hole, or whatever is appropriate for the door.
3. Use the included template to mark the mounting holes. Double check that these holes are the exact same distance from the edge of the door. Drill through the door with a 5/16" diameter bit at the marked locations.
4. Countersink the holes on the inside of the door 1/8" deep with a 9/16" drill. This will allow the screws to sit flush on the door.
5. Push the provided screws through the door, and thread onto the grip. Tighten securely.

