



POCKET DOOR MORTISE HOLE PREPARATION



NOTE:
THIS TEMPLATE IS DESIGNED FOR 1-3/8" THICK DOOR.


* NOTE: 8-1/2" X 11" COPY OF THIS TEMPLATE NOT TO SCALE.

1 Install Lock Body




See template for door prep specifications

2 Install Drive Bar Cylinder




Note: Notch on cylinder must be in the 9 o'clock position when fully screwed into lock body.

3 Mount Inside Plate




4 Mount Outside Plate




5 Thread Key Cylinder

Install Key Cylinder by threading it clockwise onto lock body plate




Key Cylinder notch must be at the 3 o'clock position when fully screwed in lock body.

6 Tighten Drive Bar Cylinder




Tighten locking screw to engage notch on cylinder

7 Install Trim Plate



8 Install Door Jamb



Drill two 7/64" pilot holes

See template for door jamb prep specifications